

Nova 71 Stereo Headphones

Your Optimus Nova 71 Stereo Headphones deliver full-frequency sound in a lightweight design. They are designed for use with the latest digital audio equipment, compact disc players, and digital compact cassette (DCC) decks, and are even light enough to use with portable CD players and personal stereos. The headband (with adjusting inner strap) provides a comfortable fit for any head size or shape.

FEATURES

Lightweight Construction — comfortably delivers the full range of dynamic sound you expect from digital sound sources.

Swivel Foam-Filled Soft Crinkled Earpads — provide a comfortable, frequency-sensitive listening experience.

High Energy, Ferrite Magnet, Mylar-Cone Speakers — deliver high-quality stereo sound.

OPERATION

Caution: Turn down the volume on your sound source before plugging in the headphones.

1. Insert the headphones' plug into a 1/8-inch stereo headphone jack on your equipment.
2. Adjust the headphones for a comfortable fit.
3. Adjust the source's volume to a comfortable level.

Listening Safely

To protect your hearing, do not listen at extremely high volume levels. Extended, high-volume listening can lead to permanent hearing loss.

Your ears adapt to higher volume levels over time, so even a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

Even though some headphones let you hear some outside sounds when listening at normal volume levels, they still can present a traffic hazard.

OPTIONAL ACCESSORIES

Stereo Y-Adapter (Cat. No. 42-2463) — lets you connect two sets of 1/8-inch stereo headphones to one 1/8-inch stereo headphone jack.

Stereo-to-Mono Adapter (Cat. No. 274-368) — lets you connect your headphones to any mono source, such as a CB set, shortwave radio, or mono audio equipment.

1/8- to 1/4-inch Stereo Plug Adapter (Cat. No. 274-348) — lets you use your headphones with any radio, stereo cassette deck, or CD player that has a 1/4-inch stereo jack.

SPECIFICATIONS

Speaker	CO4325AW
Impedance (1 KHz)	32 ohm ±15%
Frequency Response	20–20,000 Hz
Total Harmonic Distortion	Less than 3% at 95 db SPL at 1 kHz
SPL (1 mW cns)	107 ±4 dB
Cord	7.5 ft. Straight
Plug	3.5 mm Stereo Nickel Plated

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W, 100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102